TOP AND CONSOLE PARTS

ELECTRIC DRYER

For Models: LER4634EW0, LER4634EQ0, LER4634EZ0
(White)(Designer White)(Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LER4634EW0, LER4634EQ0, LER4634EZ0
(White)(Designer White)(Designer Almond)

Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console
2	688805	Clip
3	3390646	Screw, 8−18 x 5/16
4		Cap, End (L.H.) (MODEL)
	3358531	LER4634EW0
	3358528	LER4634EQ0
	3358529	LER4634EZ0
5	353425	Connector (Door Switch)
6	388326	Screw, Console
7	3395683	Housing, Connector (Motor)
8		Cap, End (R.H.) (MODEL)
	3358516	LER4634EW0
	3358513	LER4634EQ0
	3358514	LER4634EZ0
9	3388706	Resistor
10	339392	Screen, Lint
11		Cover, Lint Screen
	688150	White
	689310	Almond
12	339229	Hinge, R.H.
	339230	Hinge, L.H.
13	688983	Screw, 8−18 x 5/8
14	3390647	Screw, 8−18 x 1/2
15	693995	Screw, Hex Head
16		Top
	3396022	White
	3396023	Almond
17	3394427	Clip, Harness
21	3393934	Timer, 60 Hz.
30	357213	Nut, Push−In (2)
31	3405110	Harness, Wiring
39	3395382	Switch, Push−To−Start
48		Timer Knob Assembly (MODEL)
	3396145	LER4634EW0
	3396146	LER4634EQ0
	3396149	LER4634EZ0
53	3396293	Bracket, Control
54		Panel, Control (MODEL)
	3399047	LER4634EW0
	3399048	LER4634EQ0
	3399049	LER4634EZ0
72	690853	Wire, Ground
81		Knob, Push To Start (MODEL)
	3396160	LER4634EW0
	3396161	LER4634EQ0
	3396164	LER4634EZ0

LITERATURE AND OPTIONAL PARTS

LITERATURE PARTS

Illus. No.	Part No.	DESCRIPTION
	LIT3401094	Use & Care Guide
	LIT3397617	Instructions, Installation
	LIT3405722	Instructions, Door Reversing
	LIT3401728	Label, Wiring Diagram

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH−UP (1/2oz.)

Part No.	DESCRIPTION
72017	White
72107	Almond

PAINT, PRESSURIZED SPRAY (13 oz.)

Part No.	DESCRIPTION
350930	White
350956	Almond
350938	Primer, Gray

PAINT, BULK (1 qt.)

Part No.	DESCRIPTION
799344	White (Uncut)
978883	Almond (Uncut)

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

Part No.	DESCRIPTION
LIT677818	Dryer

CABINET PARTS

For Models: LER4634EW0, LER4634EQ0, LER4634EZ0
(White)(Designer White)(Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: LER4634EW0, LER4634EQ0, LER4634EZ0
(White)(Designer White)(Designer Almond)

Illus. No.	Part No.	DESCRIPTION
1	3405104	Harness, Wiring (Door Switch)
2	3393008	Screw, 10−16 x 1/2
3		Plug, Strike Hole
	3403630	White
	3403631	Almond
5	3396795	Cover, Terminal Block
6	694091	Screw
7	3396807	Panel, Rear
8		Plug, Hinge Hole (4)
	3404413	White
	3404414	Almond
9	342055	Screw, 8−18 x 1/2
10	347207	Switch, Door
11	98129	Screw, 6−20 x 1−3/8 (2)
12	691581	Lever, Door Switch
13	693995	Screw, Rear Panel Mounting
16	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2) (Not Included)
17	343641	Screw, 10−16 x 1/2
18		Cabinet (Includes Illus. Nos. 5, 7, 16, 29, 41 & 57)
	3399580	White
	3399581	Almond
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21		Front Panel Assembly
	3403571	White
	3403572	Almond
23	685203	Clip, Felt Pad
24	3389441	Catch, Door
28	3405514	Hinge & Pin Assembly
29	3394083	Clip, Front Panel (2)
33	3403431	Strike, Door
35	3403371	Door, Rear
36		Door Front
	3403361	White
	3403362	Almond
37		Handle, Door
	3405184	White
	3405185	Almond
38	349464	Seal & Bearing Assembly
40	279393	Terminal Block Kit For Terminal Block
41	690261	Block, Terminal
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	660996	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16−18 x 3/4
59	3401143	Pulley, 60 Hz.
62	3395652	Motor Assembly 60 Hz.
63	660658	Clamp, Motor
64	3404162	Clamp, Motor (W/Shield)
67	3390733	Seal, Door
87	697776	Screw, 10−32 x 1/2 (External Ground)
90	279318	Terminal, Tinned & Brass (3) (Includes Illus. 40)

BULKHEAD PARTS

For Models: LER4634EW0, LER4634EQ0, LER4634EZ0
(White)(Designer White)(Designer Almond)



Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute Assembly
4	3388703	Washer, Support
5	90767	Screw, 8 x 3/8
6	3399848	Thermal Cut−Off (Hi−Limit Thermostat Illus. No.15 Included)
7	347139	Seal, Lint Chute
9	3392247	Pad, Blower Housing
10	694089	Wheel, Blower
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	3397566	Box, Heater
15	3390291	Thermostat, High Limit 250°F (121.1°C) (60 Hz.)
16	3392123	Seal, Blower Shaft
17	3398064	Element, Heater (For 240 Volt Installation)
21	279457	Wire Kit (For Heater Element Wiring Harness Repair)
23	3392519	Fuse, Thermal
24	3387134	Thermostat, Internal−Bias
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8−16
48	3397264	Bulkhead
62	3394509	Ring, Bearing
63	97787	Screw, 11−16 x 7/8
66	337449	Seal, Rear Drum
67	3396777	Drum Assembly
68	342847	Baffle, Drum
69	348945	Bracket, Support
70	90296	Clip
73	339956	Seal
74	3400800	Screw, 10−16 x 1/2
75	696302	Shield, Exhaust

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST